



**Wentworth**  
Security & Fire Protection

[www.wentsec.co.uk](http://www.wentsec.co.uk)

01642 983155 - 01287 550355

Alarms - CCTV - Access Control - Fire Alarms - Fire Extinguishers - Electric Gates

### **Resetting your CCTV WIFI adapter for your new router**

- First of all you will need to download an app called 'tether' from the app store.
- Once you have done this you will need a pen! you need to go upstairs to where the cctv equipment is located and find the white plug with blue lights on.
- When you have located this on the bottom of the plug there is a recessed black button labelled 'reset' you will need to press this with the tip of the pen and hold it down for 5 seconds.
- Once you have done this all of the blue lights should come on.
- At this point you need to go on to your smartphone and go in to your settings then wifi and select the network 'tplinkextender'
- When you have connected to the network you will need to open the tether app you installed earlier
- The app will now search and hopefully should find the device, once it has select the device and set the password as 'admin'
- The app will then search for your home network, once it has found it type in the password for your wifi.
- Finally let the app run through its checks and you should be all done!